

#### • THANK YOU FOR USING •

We have purpose to provide a better life inspired by clean, hygenic and healthly lifestyles. We created design of every products with creativity but contain with comfortable and balance as a way of living. And we gladly say Thank You for believing us.

#### • CARE AND CLEANING •

The products is designed of years of trouble free performance.

By cleaning it periodically with mild soap, rinse thoroughly with warm water, and dry with a clean, soft cloth. It make your products keep looking new.

To avoid dull the finish, do not use abrasive cleaners, steel wool or harsh chemicals. Failure to follow these intructions may void your warrant.

#### CAUTION •

For safe operation of the product, please observe the following:

- \* Avoid too much force for operation.
- \* Keep the hand hold shower on the shower arm.
- \* The recommended water pressure is over 2kg²/cm².
- \* Do not dismantle the products without manual.
- TOOLS YOU WILL NEED •






### • BEFORE YOU START INSTALLATION •

#### OBSERVE ALL LOCAL PLUMBING CODES

- \* Make sure water supply is shut off.
- \* Read these instructions carefully to ensure proper installation.
- \* Our product reserves the right to update product design without notice.

\* Check to make sure you have the following parts indicated below.





Shower Head









r


1x


7T ROUND HEAD


CODE	Ball joint type RO200.001.CR - RO240.001.CR - RO300.001.CR - RO350.001.CR - RO400.001.CR Without Ball joint type RO200.002.CR - RO240.002.CR - RO300.002.CR - RO350.002.CR - RO400.002.CR
***************************************	10200.002.011 110240.002.011 110000.002.011 110400.002.011
SIZE	Ø200 mm - Ø240 mm - Ø300 mm - Ø350 mm - Ø400 mm
FINISH	Chrome Plating
ORIGIN	JoeyforLife / South Korea











RO240.001.CR

RO300.001.CR


RO350.001.CR

RO400.001.CR



					L/min
Water Pressure	200	240	300	350	400
1 Bar	8	7.3	7.3	17.4	17.5
2 Bar	9.6	9	9	22.5	22.9
3 Bar	9.7	9	9	27	28.6
4 Bar	10	9.5	9.7	27	28.6

<sup>\*</sup>Direct Connection Without Tap



# INSTALLATION


## **INSTALLATION PROCEDURE**



1.
Insert the flow rate regulator and washer on the ball joint valve.



2.
Connect the shower head tightly.



**3.** Fix the shower head with bolt.

Overhead Shower - 7T Round

# **INSTALLATION GUIDE BOOK**

